



Wallace Fixed Height Gantry Cranes

Thrifty Parts Location

Read, Understand, and Comply with all instructions supplied with this crane. Also, pay attention to the equipment used with this crane such as hoists, trolleys, power drives (if applicable), etc. Read, Understand, and Comply with the requirements of OSHA (Occupational Safety, and Health Administration) 1910.179

Parts List


Item	Description
------	-------------

- | | |
|----|-----------------------|
| 1 | I-Beam |
| 2 | End Frame |
| 3 | Caster |
| 4 | Cap Screw -- Caster |
| 5 | Lock Washer -- Caster |
| 6 | Hex Nut -- Caster |
| 7 | Cap Screw |
| 8 | Bevel Washer |
| 9 | Lock Washer |
| 10 | Hex Nut |

When ordering parts, specify Item Number, Description, and Model Number of your Gantry Crane.

CAUTION AREAS

Make sure that all CAUTION labels and safety tags are in place and legible. Inspect that rated capacity is plainly marked on each side of I-Beam. Each hoisting unit shall have its rated load clearly marked and legible from ground or floor.



FORM THRIFTY_FIX_PARTS (2/2017)

Wallace Cranes
71 N Bacton Hill Rd.
Malvern, PA 19355



www.wallacecranes.com
800-553-5438
© 2017 All rights reserved.